



一孔




二孔




三孔




四孔



五孔




六孔







一孔按钮盒  
F-86 □<sup>1</sup>  
小座触点  
F-72 □<sup>1</sup>  
大座触点



二孔按钮盒  
F-87 □<sup>1</sup>  
小座触点  
F-73 □<sup>1</sup>  
大座触点



三孔按钮盒  
F-88 □<sup>1</sup>  
小座触点  
F-74 □<sup>1</sup>  
大座触点



四孔按钮盒  
F-89 □<sup>1</sup>  
小座触点  
F-75 □<sup>1</sup>  
大座触点

